
## eSIM Installation

I have only one device, enter it manually.


## Before Going Abroad Installation

The esIM installation requires a network. It is recommended to find a stable WiFi or mobile data to install eSIM before departure.


Go to Settings >
Connections >
SIM manager



2 Tap the [Add eSIM]




Tap the [Scan QR code from service provider]



Scan QRcode



5 Enter Activation Code which is from provider




6 Checking on network and download eSIM



eSIM will be shown in the list. Click on your eSIM

Installation is successful,



( - OH4

Label the eSIM



9 Switch off the eSIM



Arrive the Destination

Switch to eSIM and turned on data roaming

[Primary SIM]

Choose current

SIM manager > Switch on the eSIM

Go to Settings >

Connections >

SIM manager

Allow secondary SIM to use data during calls? This is required to use mobile data while on phone calls using your secondary SIM. Don't allow Allow SIM cards SIM 1 Unknown Unknown number eSIMs eSIM 2 Provider Unknown number Taiwan 2 Unknown number

Japan

Provider
Unknown number

Taiwan

Provider Unknown number

China

2

eSIM

< SIM manager

Go to Settings > Connections >

Mobile networks > Toggle Mobile





You are connecting to WiFi. Please try to turn off the WiFi to see if you are connected to a 4G/5G network. If you have any questions, please contact customer service.